


# Packaged Air-Conditioners

## INDOOR UNIT


### SFZ-M25, M35, M50, M60, M71VA

INSTALLATION MANUAL	FOR INSTALLER	English
INSTALLATIONSHANDBUCH	FÜR INSTALLATEURE	Deutsch
MANUEL D'INSTALLATION	POUR L'INSTALLATEUR	Français
INSTALLATIEHANDLEIDING	VOOR DE INSTALLATEUR	Nederlands
MANUAL DE INSTALACIÓN	PARA EL INSTALADOR	Español
MANUALE DI INSTALLAZIONE	PER L'INSTALLATORE	Italiano
ΕΓΧΕΙΡΙΔΙΟ ΟΔΗΓΙΩΝ ΕΓΚΑΤΑΣΤΑΣΗΣ	ΓΙΑ ΑΥΤΟΝ ΠΟΥ ΚΑΝΕΙ ΤΗΝ ΕΓΚΑΤΑΣΤΑΣΗ	Ελληνικά
MANUAL DE INSTALAÇÃO	PARA O INSTALADOR	Português
INSTALLATIONSMANUAL	TIL INSTALLATØREN	Dansk
INSTALLATIONSMANUAL	FÖR INSTALLATÖREN	Svenska
MONTAJ ELKİTABI	MONTÖR İÇİN	Türkçe
РУКОВОДСТВО ЗА МОНТАЖ	ЗА МОНТАЖНИКА	Български
INSTRUKCJA MONTAŻU	DLA INSTALATORA	Polski
INSTALLASJONSHÅNDBOK	FOR MONTØR	Norsk
ASENNUSOPAS	ASENTAJALLE	Suomi
РУКОВОДСТВО ПО УСТАНОВКЕ	ДЛЯ УСТАНОВИТЕЛЯ	Русский
ПОСІБНИК З УСТАНОВЛЕННЯ	ДЛЯ СПЕЦІАЛІСТА З МОНТАЖУ	Українська
INSTALAČNÍ PŘÍRUČKA	PRO MONTÁŽNÍ PRACOVNÍKY	Čeština
NÁVOD NA INŠTALÁCIU	PRE MONTÉRA	Slovenčina
TELEPÍTÉSI KÉZIKÖNYV	A TELEPÍTŐ RÉSZÉRE	Magyar
NAMESTITVENI PRIROČNIK	ZA MONTERJA	Slovenščina
MANUAL DE INSTALARE	PENTRU INSTALATOR	Română
PAIGALDUSJUHEND	PAIGALDAJALE	Eesti
MONTĀŽAS ROKASGRĀMATA	UZSTĀDĪŠANAS SPECIĀLISTAM	Latviski
MONTAVIMO VADOVAS	SKIRTA MONTUOTOJUI	Lietuviškai
PRIRUČNIK ZA POSTAVLJANJE	ZA INSTALATERA	Hrvatski
UPUTSTVO ZA UGRADNJU	ZA MONTERA	Srpski

[Fig. 3-0-1]




[Fig. 3-1-1]



	(mm)	
Model name	(A)	(B)
SFZ-M25	700	More than 240
SFZ-M35,50	900	More than 240
SFZ-M60,71	1100	More than 240

- (A) Floor
- (B) Piping space
- (C) Electrical part service space


[Fig. 4-1-1]



- (A) Leg
- (B) Screw

[Fig. 4-1-2]


For fixing on the floor  
<Viewed from top of the unit>



- (C) Wall

[Fig. 4-1-3]

For fixing on the wall  
<Viewed from front of the unit>




(mm)

Model name	(E)	(F)
SFZ-M25	730	756
SFZ-M35,50	930	956
SFZ-M60,71	1130	1156


- (A) Floor

[Fig. 4-1-4]




- (A) Nuts (field supply)
- (B) Washers
- (C) M10 Hanging bolt (field supply)

[Fig. 4-1-5]




- (A) Filter
- (B) Fan guard
- (C) Front plate


**[Fig. 4-1-6]**  
**For fixing on the wall**  
 <Viewed from front of the unit>



**[Fig. 4-3-1]**



[Fig. 5-1]




Model	A	B
SFZ-M25, 35	9.52	6.35
SFZ-M50	12.7	6.35
SFZ-M60	15.88	6.35
SFZ-M71	15.88	9.52

- Ⓐ Indoor unit
- Ⓑ Outdoor unit


5.2

[Fig. 5-2-1]




- Ⓐ Copper tubes
- Ⓑ Good
- Ⓒ No good
- Ⓓ Tilted
- Ⓔ Uneven
- Ⓕ Burred

[Fig. 5-2-2]




- Ⓐ Burr
- Ⓑ Copper tube/pipe
- Ⓒ Spare reamer
- Ⓓ Pipe cutter

[Fig. 5-2-3]




- Ⓐ Flare nut
- Ⓑ Copper tube

[Fig. 5-2-4]




- Ⓐ Flaring tool
- Ⓑ Die
- Ⓒ Copper tube
- Ⓓ Flare nut
- Ⓔ Yoke

[Fig. 5-2-5]



- Ⓐ Smooth all around
- Ⓑ Inside is shining without any scratches
- Ⓒ Even length all around
- Ⓓ Too much
- Ⓔ Tilted
- Ⓕ Scratch on flared plane
- Ⓖ Cracked
- Ⓗ Uneven
- Ⓘ Bad examples


[Fig. 5-3-1]







• After removing 8 screws, cover 1 and cover 2 are removed.

- Ⓐ Cover 1
- Ⓑ Cover 2

[Fig. 5-3-2]



[Fig. 5-3-3]



(Unit: mm)


- Ⓐ Pipe cover (small) (accessory)
- Ⓑ Pipe cover (middle) (accessory)
- Ⓒ Liquid end of refrigerant piping
- Ⓓ Gas end of refrigerant piping
- Ⓔ Site refrigerant piping
- Ⓕ Main body

- Ⓖ Pipe cover (large) (accessory)
- Ⓗ Plate on main body
- Ⓘ Ensure that there is no gap here.
- Ⓝ Flare nut
- Ⓚ Thermal insulation (field supply)
- Ⓛ Cut thermal insulation by 75 mm.

- Ⓜ Band (accessory)
- Ⓝ Ensure that there is no gap here. Place join upwards.
- Ⓞ Cover 1
- Ⓟ Cover 2

5.5


[Fig. 5-5-1]



- Ⓐ Downward slope 1/100 or more
- Ⓑ Drain hose (Accessory)
- Ⓒ Indoor unit
- Ⓓ Collective piping

[Fig. 5-5-2]


(Unit: mm)



- Ⓐ Indoor unit
- Ⓑ Tie band (accessory)
- Ⓒ Band fixing part
- Ⓓ Insertion margin
- Ⓔ Drain hose (accessory)
- Ⓕ Drain pipe (O.D. ø32 PVC TUBE, field supply)
- Ⓖ Insulating material (field supply)

6

[Fig. 6-0-1]




- Ⓐ Air inlet
- Ⓑ Air filter
- Ⓒ Duct
- Ⓓ Canvas duct
- Ⓔ Access door
- Ⓕ Wall
- Ⓖ Air outlet


7

7.1

[Fig. 7-1]




[Fig. 7-2-1]




- (A) Screw holding cover (3 pcs.)
- (B) Cover

[Fig. 7-2-2]




- (A) Terminal bed box
- (B) Knockout hole
- (C) Remove

[Fig. 7-2-3]




- (A) Use a cable tie to secure the cable.
- (B) Use PG bushing to keep the weight of the cable and external force from being applied to the power supply terminal connector.
- (C) Indoor/outdoor unit connecting wire
- (D) Use ordinary bushing
- (E) Terminal bed for power source and indoor transmission
- (F) Terminal block for remote controller
- (G) Transmission line to the remote controller

[Fig. 7-2-4]




- (A) Indoor terminal block
- (B) Earth wire (green/yellow)
- (C) Indoor/outdoor unit connecting wire 3-core 1.5 mm<sup>2</sup> or more
- (D) Outdoor terminal block
- (E) Power supply cord
- ① Connecting cable  
Cable 3-core 1.5 mm<sup>2</sup>, in conformity with Design 245 IEC 57.
- ② Indoor terminal block
- ③ Outdoor terminal block
- ④ Always install an earth wire (1-core 1.5 mm<sup>2</sup>) longer than other cables
- ⑤ Remote controller cable  
Wire No × size (mm<sup>2</sup>): Cable 2C × 0.3  
This wire accessory of remote controller  
(wire length : 10 m, non-polar. Max. 500 m)
- ⑥ Wired remote controller (option)
- ⑦ Power supply cord


[Fig. 7-4-1]




[Fig. 7-4-2]




[Fig. 7-4-3]




[Fig. 7-4-4]




[Fig. 7-4-5]




[Fig. 7-5-1]




[Fig. 7-6-1]



[Fig. 7-6-2]




[Fig. 7-6-3]



[Fig. 7-6-4]




[Fig. 7-6-5]



- Ⓐ Hour button
- Ⓑ Minute button
- Ⓒ TEMP button
- Ⓓ TEMP button
- Ⓔ ON/OFF button
- Ⓕ CHECK button

# 8

[Fig. 8-0-1]




# 9

## 9.2


[Fig. 9-2-1]



[Fig. 9-2-2]



[Fig. 9-2-3]




- Ⓐ TEST RUN button
- Ⓑ MODE button
- Ⓒ FAN button
- Ⓓ VANE button

# 10

## 10.1

[Fig. 10-1]



- Ⓐ Indoor unit
- Ⓑ Union
- Ⓒ Liquid pipe
- Ⓓ Gas pipe
- Ⓔ Stop valve
- Ⓕ Outdoor unit
- Ⓖ Refrigerant gas cylinder operating valve
- Ⓗ Refrigerant gas cylinder for R32 with siphon
- Ⓘ Refrigerant (liquid)
- Ⓙ Electronic scale for refrigerant charging
- Ⓚ Charge hose (for R32)
- Ⓛ Gauge manifold valve (for R32)
- Ⓜ Service port

# Contents

1. Safety precautions.....	12	6. Duct work .....	18
2. Selecting the installation location .....	14	7. Electrical work .....	18
3. Selecting an installation site & Accessories .....	14	8. How to attach the label and the explanation .....	20
4. Installing the unit .....	15	9. Test run.....	21
5. Refrigerant piping work .....	16	10. Maintenance.....	24





This Installation Manual describes only for the indoor unit and the connected outdoor unit of SUZ series.  
If the connected outdoor unit is MXZ series, refer to the Installation Manual for MXZ series.

**Note:**  
The phrase “Wired remote controller” in this installation manual refers only to the PAR-40MAA. If you need any information for the other remote controller, please refer to either the installation manual or initial setting manual which are included in these boxes.


## 1. Safety precautions

- ▶ Before installing the unit, make sure you read all the “Safety Precautions”.
- ▶ The “Safety Precautions” provide very important points regarding safety. Make sure you follow them.
- ▶ Please report to or take consent by the supply authority before connection to the system.

### MEANINGS OF SYMBOLS ON THE UNIT

	<b>WARNING</b> (Risk of fire)	This symbol is only for R32 refrigerant. The type of the refrigerant used is written on the nameplate on the outdoor unit. R32 refrigerant is flammable. If the refrigerant leaks, or comes in contact with fire or parts that generate heat, it may create harmful gas and pose a risk of fire.
		Read the OPERATION MANUAL carefully before operation.
		Service personnel are required to carefully read the OPERATION MANUAL and INSTALLATION MANUAL before operation.
		Further information is available in the OPERATION MANUAL, INSTALLATION MANUAL, and the like.


- Please report to or take consent by the supply authority before connection to the system.
- Be sure to read “Safety precautions” before installing the air conditioner.
- Be sure to observe the cautions specified here as they include important items related to safety.
- The indications and meanings are as follows.

 **Warning:**  
Could lead to death, serious injury, etc.









 **Caution:**  
Could lead to serious injury in particular environments when operated incorrectly.

 **Warning:**  
Describes precautions that must be observed to prevent danger of fire.

- After reading this manual, be sure to keep it together with the instruction manual in a handy place on the customer's site.

-  **Warning:**
- Do not use refrigerant other than the type indicated in the manuals provided with the unit and on the nameplate.
    - Doing so may cause the unit or pipes to burst, or result in explosion or fire during use, during repair, or at the time of disposal of the unit.
    - It may also be in violation of applicable laws.
    - MITSUBISHI ELECTRIC CORPORATION cannot be held responsible for malfunctions or accidents resulting from the use of the wrong type of refrigerant.
  - When handling this product, always wear protective equipment.  
EG: Gloves, full arm protection namely boiler suit, and safety glasses.
    - Improper handling may result in injury.
  - Do not install it by yourself (customer).  
Incomplete installation could cause injury due to fire, electric shock, the unit falling or leakage of water. Consult the dealer from whom you purchased the unit or special installer.
  - This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
  - Install the unit securely in a place which can bear the weight of the unit. When installed in an insufficient strong place, the unit could fall causing injured.
  - Use the specified wires to connect the indoor and outdoor units securely and attach the wires firmly to the terminal board connecting sections so the stress of the wires is not applied to the sections.  
Incomplete connecting and fixing could cause fire.
  - Do not use intermediate connection of the power cord or the extension cord and do not connect many devices to one AC outlet.  
It could cause a fire or an electric shock due to defective contact, defective insulation, exceeding the permissible current, etc.
  - Check that the refrigerant gas does not leak after installation has completed.

### Symbols put on the unit

-  : Indicates an action that must be avoided.
-  : Indicates that important instructions must be followed.
-  : Indicates a part which must be grounded.
-  : Indicates that caution should be taken with rotating parts.
-  : Indicates that the main switch must be turned off before servicing.
-  : Beware of electric shock.
-  : Beware of hot surface.
-  **Warning:**  
Carefully read the labels affixed to the main unit.

- Perform the installation securely referring to the installation manual. Incomplete installation could cause a personal injury due to fire, electric shock, the unit falling or leakage of water.
- Perform electrical work according to the installation manual and be sure to use an exclusive circuit.  
If the capacity of the power circuit is insufficient or there is incomplete electrical work, it could result in a fire or an electric shock.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Attach the electrical part cover to the indoor unit and the service panel to the outdoor unit securely.  
If the electrical part cover in the indoor unit and/or the service panel in the outdoor unit are not attached securely, it could result in a fire or an electric shock due to dust, water, etc.
- Be sure to use the part provided or specified parts for the installation work. The use of defective parts could cause an injury or leakage of water due to a fire, an electric shock, the unit falling, etc.
- Ventilate the room if refrigerant leaks during operation.
- If the refrigerant comes in contact with a flame, poisonous gases will be released.
- Children should be supervised to ensure that they do not play with the appliance.
- The installer and system specialist shall secure safety against leakage according to local regulation or standards.
  - The instructions in this manual may be applicable if local regulation are not available.
- Pay a special attention to the place, such as a basement, etc. where refrigeration gas can stay, since refrigeration is heavier than the air.
- This appliance is intended to be used by expert or trained users in shops, in light industry and on farms, or for commercial use by lay persons.

# 1. Safety precautions

- **When installing, relocating, or servicing the air conditioner, use only the specified refrigerant written on the outdoor unit to charge the refrigerant lines. Do not mix the refrigerant with any other refrigerant, and do not allow air to remain in the lines.**
  - If air is mixed with the refrigerant, then it may cause abnormal high pressure in the refrigerant lines, resulting in an explosion and other hazards.
  - The use of any refrigerant other than that specified for the system will cause mechanical failure, system malfunction, or unit breakdown. In the worst case, this could lead to a serious impediment to securing product safety.
  - It may also be in violation of applicable laws.
  - MITSUBISHI ELECTRIC CORPORATION cannot be held responsible for malfunctions or accidents resulting from the use of the wrong type of refrigerant.
- **Only use means recommended by the manufacturer to accelerate the defrosting process or to clean.**
- **This indoor unit shall be stored in a room that has no continuously-operating ignition device such as open flame, gas appliance, or electrical heater.**
- **Do not pierce a hole in or burn this indoor unit or refrigerant lines.**
- **Be aware that the refrigerant may be odour-free.**
- **Pipe-work shall be protected from physical damage.**
- **The installation of pipe-work shall be kept to a minimum.**
- **Compliance with national gas regulations shall be observed.**
- **Keep any required ventilation openings clear of obstruction.**
- **Do not use low temperature solder alloy when brazing the refrigerant pipes.**
- **When performing brazing work, be sure to ventilate the room sufficiently. Make sure that there are no hazardous or flammable materials nearby. When performing the work in a closed room, small room, or similar location, make sure that there are no refrigerant leaks before performing the work. If refrigerant leaks and accumulates, it may ignite or poisonous gases may be released.**
- **For installation and relocation work, follow the instructions in the installation manual and use tools and pipe components specifically made for using with refrigerant specified in the outdoor unit installation manual.**
- **Do not turn the breaker off except when a burning smell is noticed or to perform maintenance or inspection. Turning off the breaker will cut off the power supply to the refrigerant leak sensor on the indoor unit, rendering the sensor unable to detect refrigerant leakage. Failure to detect refrigerant leakage may result in fire.**

## Caution:

- **Perform grounding.**  
Do not connect the ground wire to a gas pipe, water pipe arrester or telephone ground wire. Defective grounding could cause an electric shock.
- **Do not install the unit in a place where an inflammable gas leaks.**  
If gas leaks and accumulates in the area surrounding the unit, it could cause an explosion.
- **Install a ground leakage breaker depending on the installation place (where it is humid).**  
If a ground leakage breaker is not installed, it could cause an electric shock.
- **Perform the drainage/piping work securely according to the installation manual.**  
If there is a defect in the drainage/piping work, water could drop from the unit and household goods could be wet and damaged.
- **Fasten a flare nut with a torque wrench as specified in this manual.**  
When fastened too tight, a flare nut may broken after a long period and cause a leakage of refrigerant.
- **When the breaker is turned on, the fan may suddenly go into operation. Note that the fan will automatically go into operation when a refrigerant leak is detected by the refrigerant sensor. Keep a safe distance from the fan to avoid injury.**
- **When using any aerosol sprays for interior construction, finishing work, or sealing a wall hole, turn off the breaker and ventilate the room well. The refrigerant sensor may react to the gas in the sprays, and it may cause misdetection.**

## 2. Selecting the installation location

### 2.1. Indoor unit

- Where airflow is not blocked.
- Where cool air spreads over the entire room.
- Where it is not exposed to direct sunshine.
- At a site that allows for proper drainage of drain water.
- At a distance 1 m or more away from your TV and radio (to prevent picture from being distorted or noise from being generated).
- In a place as far away as possible from fluorescent and incandescent lights (so the infrared remote control can operate the air conditioner normally).
- Where the air filter can be removed and replaced easily.

### 2.2. Outdoor unit

- Where it is not exposed to strong wind.
- Where airflow is good and dustless.
- Where it is not exposed to rain and direct sunshine.
- Where neighbours are not annoyed by operation sound or hot air.
- Where rigid wall or support is available to prevent the increase of operation sound or vibration.
- Where there is no risk of combustible gas leakage.
- When installing the unit at a high level, be sure to fix the unit legs.
- Where it is at least 3 m away from the antenna of TV set or radio. (Otherwise, images would be disturbed or noise would be generated.)
- Install the unit horizontally.

#### ⚠ Caution:

**Avoid the following places for installation where air conditioner trouble is liable to occur.**

- **Where there is too much machine oil.**
- **Salty environment as seaside areas.**
- **Hot-spring areas.**
- **Where sulfide gas exists.**
- **Other special atmospheric areas.**

## 3. Selecting an installation site & Accessories

- Select a site with sturdy fixed surface sufficiently durable against the weight of unit.
- Before installing unit, the routing to carry in unit to the installation site should be determined.
- Select a site where the unit is not affected by entering air.
- Select a site where the flow of supply and return air is not blocked.
- Select a site where refrigerant piping can easily be led to the outside.
- Select a site which allows the supply air to be distributed fully in room.
- Do not install unit at a site with oil splashing or steam in much quantity.
- Do not install unit at a site where combustible gas may generate, flow in, stagnate or leak.
- Do not install unit at a site where equipment generating high frequency waves (a high frequency wave welder for example) is provided.
- Do not install unit at a site where fire detector is located at the supply air side. (Fire detector may operate erroneously due to the heated air supplied during heating operation.)
- When special chemical product may scatter around such as site chemical plants and hospitals, full investigation is required before installing unit. (The plastic components may be damaged depending on the chemical product applied.)
- Keep the unit away from heat or steam source.
- Do not install the unit in a place where the following types of appliances or chemicals are used nearby or where sulfur gas is present: propane, butane, or methane appliances; spray cans, such as insect repellent; or equipment that generates smoke or paint.
- The refrigerant sensor on the indoor unit may react to these chemicals, resulting in an error, and the unit may become inoperable.
- If the unit is operated for long hours in a high-temperature high-humidity environment (dew point above 26°C), condensation may form on the indoor unit. When operating the indoor unit under such condition, insulate the entire surface of the indoor unit with insulation materials (10-20 mm thick).

#### ⚠ Warning:

**The unit must be securely installed on a structure that can sustain its weight. If the unit is mounted on an unstable structure, it may fall down causing injuries.**

#### ⚠ Warning:

1. **Install the unit in a space with at least a minimum floor area defined in the installation manual for the outdoor unit.**
  - Refer to the installation manual for the outdoor unit.
2. **This unit has a function to detect refrigerant leaks and force the fan to go into operation to reduce the refrigerant concentration. For this function to work effectively, observe the following.**
  - **Do not obstruct the inlets or outlets.**
  - **Install the unit where the supply air can be evenly distributed throughout the space.**

Indoor units connected to an outdoor unit for use with R32 must be installed in a space with at least the floor area  $A_{min}$  required for refrigerant M (factory charge+locally added amount). Refer to the installation manual for the outdoor unit for the pre-charged and post-charged refrigerant amount.

The floor areas shown in the table do not include the space occupied by furniture and other objects in the room. Make sure there is sufficient free space in the room.

M [kg]	$A_{min}$ [m <sup>2</sup> ]		
	$h \geq 1.8$	$1.4 \leq h < 1.8$	$1.0 \leq h < 1.4$
1.00	No requirements		
1.10			
1.20			
1.30			
1.40			
1.50			
1.60			
1.70			
1.80			
1.84			
1.90	4.6	5.9	8.3
2.00	4.9	6.3	8.7
2.10	5.1	6.6	9.2
2.20	5.4	6.9	9.6
2.30	5.6	7.2	10.0
2.40	5.8	7.5	10.5

M [kg]	$A_{min}$ [m <sup>2</sup> ]		
	$\theta = 90^\circ$	$60^\circ \leq \theta < 90^\circ$	$30^\circ \leq \theta < 60^\circ$
1.00	No requirements		
1.10			
1.20			
1.30			
1.40			
1.50			
1.60			
1.70			
1.80			
1.84			
1.90	4.3	5.1	8.6
2.00	4.5	5.4	9.0
2.10	4.7	5.7	9.5
2.20	4.9	5.9	9.9
2.30	5.2	6.2	10.4
2.40	5.4	6.5	10.8

Refer to the installation manual for the outdoor unit for information regarding refrigerant charge.

#### Note:

- **The air outlet height must be 1.0 m or higher.**
- **The air outlet angle must be 30° or greater.**

[Fig. 3-0-1] (P.2)

- Ⓐ Air inlet
- Ⓑ Air outlet
- Ⓒ Air outlet grill (field supply)

### 3. Selecting an installation site & Accessories

#### 3.1. Securing installation and service space

Model name	(mm)	
	(A)	(B)
SFZ-M25	700	More than 240
SFZ-M35,50	900	More than 240
SFZ-M60,71	1100	More than 240

[Fig. 3-1-1] (P.2)

- (A) Floor
- (B) Piping space
- (C) Electrical part service space

### 4. Installing the unit

#### 4.1. Assembling the unit

Install the unit frame in parallel with the floor securely when installing. There are the following two methods of installing the unit.

##### For fixing on the floor

[Fig. 4-1-1] [Fig. 4-1-2] (P.3)  
<Viewed from top of the unit>

- (A) Leg
- (B) Screw
- (C) Wall

##### For fixing on the wall

[Fig. 4-1-3] (P.3)  
<Viewed from front of the unit>

- (A) Floor

Model name	(mm)	
	(E)	(F)
SFZ-M25	730	756
SFZ-M35,50	930	956
SFZ-M60,71	1130	1156

► To fix the indoor unit on the wall, use the hanging bolts.

[Fig. 4-1-4] (P.3)

- (A) Nuts (field supply)
- (B) Washers
- (C) M10 Hanging bolt (field supply)

► When the unit is installed on the wall, vibrations may be transmitted to the wall. Take measures against vibrations as needed at the site.

#### 4.2. Procedure for changing the bottom inlet to the front inlet

[Fig. 4-1-5] (P.3)

- (A) Filter
- (B) Fan guard
- (C) Front plate

1. Remove air filter and fan guard.
2. Remove the bottom plate.
3. Fit the front plate to the bottom of the body.
4. Fit air filter and fan guard.

##### ⚠ Caution:

When the air inlet is in the front of the unit, the sound pressure will be approximately 5 dB higher compared with when the air inlet is at the bottom of the unit.

##### For fixing on the wall

[Fig. 4-1-6] (P.4)  
<Viewed from front of the unit>

- (A) Floor

► When the unit is installed on the wall, vibrations may be transmitted to the wall. Take measures against vibrations as needed at the site.

#### 3.2. Indoor unit accessories

The unit is provided with the following accessories:

No.	Name	Quantity
①	Pipe cover (for refrigerant piping joint) Small diameter	1
②	Pipe cover (for refrigerant piping joint) Middle diameter	1
③	Pipe cover (for refrigerant piping joint) Large diameter	2
④	Bands for temporary tightening of pipe cover and drain hose	10
⑤	Washer	8
⑥	Drain hose	1
⑦	Leg	2
⑧	Screw	6
⑨	Breaker tag	1
⑩	Breaker notice	1

#### 4.3. Center of gravity and product weight

[Fig. 4-3-1] (P.4)

(A) Floor hole for fixing

Model name	W (mm)	L (mm)	X (mm)	Y (mm)	Z (mm)	Product weight (kg)
SFZ-M25	730	95	5	365	290	19
SFZ-M35	930	95	5	495	300	22.5
SFZ-M50	930	95	5	495	300	22.5
SFZ-M60	1130	95	5	615	320	26
SFZ-M71	1130	95	5	615	320	26

#### 4.4. Confirming the unit's position and fixing hanging bolts

- Ensure that the hanging bolt nuts are tightened to fix the hanging bolts.
- To ensure that drain is discharged, be sure to hang the unit at level using a level.

##### ⚠ Caution:

Install the unit in horizontal position. If the side with drain port is installed higher, water leakage may be caused.

## 5. Refrigerant piping work

### 5.1. Refrigerant pipe

[Fig. 5-1] (P.5)

- Ⓐ Indoor unit
- Ⓑ Outdoor unit

Refer to the Instruction Manual that came with the outdoor unit for the restrictions on the height difference between units and for the amount of additional refrigerant charge.

Avoid the following places for installation where air conditioner trouble is liable to occur.

- Where there is too much oil such as for machine or cooking.
- Salty environment as seaside areas.
- Hot-spring areas.
- Where sulfide gas exists.
- Other special atmospheric areas.
- This unit has flared connections on both indoor and outdoor sides. (Fig. 5-1)
- Insulate both refrigerant and drainage piping completely to prevent condensation.

#### Piping preparation

- Refrigerant pipes of 3, 5, 7, 10 and 15 m are available as optional items.

(1) Table below shows the specifications of pipes commercially available.

Model	Pipe	Outside diameter		Min wall thickness	Insulation thickness	Insulation material
		mm	inch			
SFZ-M25	For liquid	6.35	1/4	0.8 mm	8 mm	Heat resisting foam plastic 0.045 specific gravity
	For gas	9.52	3/8	0.8 mm	8 mm	
SFZ-M35	For liquid	6.35	1/4	0.8 mm	8 mm	
	For gas	9.52	3/8	0.8 mm	8 mm	
SFZ-M50	For liquid	6.35	1/4	0.8 mm	8 mm	
	For gas	12.7	1/2	0.8 mm	8 mm	
SFZ-M60	For liquid	6.35	1/4	0.8 mm	8 mm	
	For gas	15.88	5/8	1.0 mm	8 mm	
SFZ-M71	For liquid	9.52	3/8	0.8 mm	8 mm	
	For gas	15.88	5/8	1.0 mm	8 mm	

(2) Ensure that the 2 refrigerant pipes are well insulated to prevent condensation.

(3) Refrigerant pipe bending radius must be 10 cm or more.

#### ⚠ Caution:

Using careful insulation of specified thickness. Excessive thickness prevents storage behind the indoor unit and smaller thickness causes dew dripage.

#### ⚠ Warning:

To reduce the risk of fire, embed or protect the refrigerant pipes. Damage to the refrigerant pipes can lead to fire.

### 5.2. Flaring work

- Main cause of gas leakage is defect in flaring work.
- Carry out correct flaring work in the following procedure.

#### 5.2.1. Pipe cutting

[Fig. 5-2-1] (P.5)

- Ⓐ Copper tubes
- Ⓑ Good
- Ⓒ No good
- Ⓓ Tilted
- Ⓔ Uneven
- Ⓕ Burred

- Using a pipe cutter cut the copper tube correctly.

#### 5.2.2. Burrs removal

[Fig. 5-2-2] (P.5)

- Ⓐ Burr
- Ⓑ Copper tube/pipe
- Ⓒ Spare reamer
- Ⓓ Pipe cutter

- Completely remove all burrs from the cut cross section of pipe/tube.
- Put the end of the copper tube/pipe to downward direction as you remove burrs in order to avoid burrs drop in the tubing.

#### 5.2.3. Putting nut on

[Fig. 5-2-3] (P.5)

- Ⓐ Flare nut
- Ⓑ Copper tube

- Remove flare nuts attached to indoor and outdoor unit, then put them on pipe/ tube having completed burr removal.
- (not possible to put them on after flaring work)
- Use the flare nut included with this indoor unit.

### 5.2.4. Flaring work

[Fig. 5-2-4] (P.5)

- Ⓐ Flaring tool
- Ⓑ Die
- Ⓒ Copper tube
- Ⓓ Flare nut
- Ⓔ Yoke

- Carry out flaring work using flaring tool as shown below.

Pipe diameter (mm)	Dimension	
	A (mm)	B <sup>+0</sup> / <sub>-0.4</sub> (mm)
	When the tool for R32 is used Clutch type	
6.35	0 - 0.5	9.1
9.52	0 - 0.5	13.2
12.7	0 - 0.5	16.6
15.88	0 - 0.5	19.7

Firmly hold copper tube in a die in the dimension shown in the table at above.

- When reconnecting the detached refrigerant pipes, make sure to flare them again.

#### 5.2.5. Check

[Fig. 5-2-5] (P.5)

- Ⓐ Smooth all around
- Ⓑ Inside is shining without any scratches
- Ⓒ Even length all around
- Ⓓ Too much
- Ⓔ Tilted
- Ⓕ Scratch on flared plane
- Ⓖ Cracked
- Ⓗ Uneven
- Ⓖ Bad examples

- Compare the flared work with a figure in right side hand.
- If flare is noted to be defective, cut off the flared section and do flaring work again.

### 5.3. Pipe connection

Before connecting the pipe, remove the cover.

[Fig. 5-3-1] (P.6)

- Ⓐ Cover 1
- Ⓑ Cover 2

- After removing 8 screws, cover 1 and cover 2 are removed.

[Fig. 5-3-2] (P.6)

- Apply a thin coat of refrigeration oil on the seat surface of pipe.
- For connection first align the center, then tighten the first 3 to 4 turns of flare nut.
- Use tightening torque table below as a guideline for indoor unit side union joint section, and tighten using two wrenches. Excessive tightening damages the flare section.

Copper pipe O.D. (mm)	Flare nut O.D. (mm)	Tightening torque (N·m)
ø6.35	17	14 - 18
ø9.52	22	34 - 42
ø12.7	26	49 - 61
ø15.88	29	68 - 82

#### ⚠ Warning:

Be careful of flying flare nut! (Internally pressurized)

Remove the flare nut as follows:

1. Loosen the nut until you hear a hissing noise.
2. Do not remove the nut until the gas has been completely released (i.e., hissing noise stops).
3. Check that the gas has been completely released, and then remove the nut.

Reusable mechanical connectors and flared joints cannot be used indoors. When connecting the refrigerant piping by brazing instead of using flare connections, complete all brazing work prior to connecting indoor unit to outdoor unit.

#### Outdoor unit connection

Connect pipes to stop valve pipe joint of the outdoor unit in the same manner applied for indoor unit.

- For tightening use a torque wrench or spanner, and use the same tightening torque applied for indoor unit.

## 5. Refrigerant piping work

### Refrigerant pipe insulation

- After connecting refrigerant piping, insulate the joints (flared joints) with thermal insulation tubing.

#### [Fig. 5-3-3] (P.6)

- |                                     |                    |
|-------------------------------------|--------------------|
| Ⓐ Pipe cover (small) (accessory)    | Ⓜ Band (accessory) |
| Ⓑ Pipe cover (middle) (accessory)   | Ⓝ Cover 1          |
| Ⓒ Liquid end of refrigerant piping  | Ⓓ Cover 2          |
| Ⓓ Gas end of refrigerant piping     |                    |
| Ⓔ Site refrigerant piping           |                    |
| Ⓕ Main body                         |                    |
| Ⓖ Pipe cover (large) (accessory)    |                    |
| Ⓗ Plate on main body                |                    |
| Ⓘ Ensure that there is no gap here. |                    |
- Remove and discard the rubber bung which is inserted in the end of the unit piping.
  - Flare the end of the site refrigerant piping.
  - Cut the refrigerant pipe insulator 75 mm from the end of the pipe.
  - Connect the pipes.
  - Wrap the supplied pipe covers (small and middle) where the pipe insulator was cut away in step 3, leaving no gap in between.
  - Wrap the supplied pipe cover (large) around the pipe so that there will be no gap between the pipe cover and the unit. The edges of the cover must be joined together without any gap, and the joined edges must be facing up.
  - Hold the both ends of the pipe cover (large) with the supplied bands.
  - Install Cover 2, then Cover 1.


#### ⚠ Warning:

Properly install covers 1 and 2 in accordance with the procedures explained above. Otherwise, R32 leakage may become undetectable.

#### Cautions On Refrigerant Piping

- Be sure to use non-oxidative brazing for brazing to ensure that no foreign matter or moisture enter into the pipe.
- Be sure to apply refrigerating machine oil over the flare connection seating surface and tighten the connection using a double spanner.
- Provide a metal brace to support the refrigerant pipe so that no load is imparted to the indoor unit end pipe. This metal brace should be provided 50 cm away from the indoor unit's flare connection.

### 5.4. Purging procedures leak test



## 5. Refrigerant piping work

### 5.5. Drain piping work

- Ensure that the drain piping is downward (pitch of more than 1/100) to the outdoor (discharge) side. Do not provide any trap or irregularity on the way. (①)
- Ensure that any cross-wise drain piping is less than 20 m (excluding the difference of elevation). If the drain piping is long, provide metal braces to prevent it from waving. Never provide any air vent pipe. Otherwise drain may be ejected.
- Use a hard vinyl chloride pipe VP-25 (with an external diameter of 32 mm) for drain piping.
- Do not provide any odor trap at the drain discharge port.
- Put the end of the drain piping in a position where no odor is generated.
- Do not put the end of the drain piping in any drain where ionic gases are generated.

**[Fig. 5-5-1] (P.6)**

- Ⓐ Downward slope 1/100 or more
- Ⓑ Drain hose (Accessory)
- Ⓒ Indoor unit
- Ⓓ Collective piping

1. Insert the drain hose (accessory) into the drain port.  
The connecting part between the indoor unit and the drain hose may be disconnected at the maintenance. Fix the part with the accessory band, not be adhered.
2. Attach the drain pipe (O.D. ø32 PVC TUBE, field supply).  
(Attach the pipe with glue for the hard vinyl chloride pipe, and fix it with the band (small, accessory).)
3. Perform insulation work on the drain pipe (O.D. ø32 PVC TUBE) and on the socket (including elbow).

**[Fig. 5-5-2] (P.6)**

- Ⓐ Indoor unit
- Ⓑ Tie band (accessory)
- Ⓒ Band fixing part
- Ⓓ Insertion margin
- Ⓔ Drain hose (accessory)
- Ⓕ Drain pipe (O.D. ø32 PVC TUBE, field supply)
- Ⓖ Insulating material (field supply)

## 6. Duct work

- When connecting ducts, insert a canvas duct between the main body and the duct.
- Use non-combustible duct components.
- Install sufficient thermal insulation to prevent condensation forming on air inlet and air outlet duct flanges, and air outlet ducts.

**[Fig. 6-0-1] (P.7)**

- Ⓐ Air inlet
- Ⓑ Air filter
- Ⓒ Duct
- Ⓓ Canvas duct
- Ⓔ Access door
- Ⓕ Wall
- Ⓖ Air outlet

## 7. Electrical work

### 7.1. Power supply

#### 7.1.1. Indoor unit power supplied from outdoor unit

The following connection patterns are available.  
The outdoor unit power supply patterns vary on models.

**[Fig. 7-1] (P.7)**

- Ⓐ Indoor unit
- Ⓑ Outdoor unit
- Ⓒ Wired remote controller
- Ⓓ Main switch/fuse
- Ⓔ Grounding

Field electrical wiring

Indoor unit model		SFZ
Wiring Wire No. × size (mm <sup>2</sup> )	Indoor unit power supply (Heater)	-
	Indoor unit power supply (Heater) earth	-
	Indoor unit-Outdoor unit	3 × 1.5 (polar)
	Indoor unit-Outdoor unit earth	1 × Min. 1.5
Circuit rating	Remote controller-Indoor unit	*1 2 × 0.3 (Non-polar)
	Indoor unit (Heater) L-N	*2 -
	Indoor unit-Outdoor unit S1-S2	*2 230 V AC
	Indoor unit-Outdoor unit S2-S3	*2 24 V DC
	Remote controller-Indoor unit	*2 14 V DC

\*1 The 10 m wire is attached in the remote controller accessory. Max. 500 m

\*2 The figures are NOT always against the ground. S3 terminal has 24 V DC against S2 terminal. However between S3 and S1, these terminals are not electrically insulated by the transformer or other device.

**Notes:**

1. Wiring size must comply with the applicable local and national code.
2. Power supply cords and indoor unit/outdoor unit connecting cords shall not be lighter than polychloroprene sheathed flexible cord. (Design 245 IEC57)
3. Install an earth longer than other cables.
4. Indoor and outdoor connecting wires have polarities. Make sure to match the terminal number (S1, S2, S3) for correct wirings.
5. Wiring for remote controller cable shall be apart (5 cm, 2 inch or more) from power source wiring so that it is not influenced by electric noise from power source wiring.

### 7.2. Indoor wire connection

Work procedure

1. Remove the screws holding the cover to dismount the cover.
2. Punch out the knockout holes. (Recommended tool: screwdriver)
3. Route each cable through the wiring intake into the electric component box. (Procure power cable and in-out connecting cable locally and use remote control cable supplied with the unit.)
4. Securely connect the power cable and the in-out connecting cable and the remote control cable to the terminal blocks.
5. Secure the cables with clamps inside the electric component box.
6. Attach the electric component cover as it was.
  - Fix power supply cable and indoor/outdoor cable to control box by using buffer bushing for tensile force. (PG connection or the like.)

**⚠ Warning:**

- Attach the electrical part cover securely. If it is attached incorrectly, it could result in a fire, electric shock due to dust, water, etc.
- Use the specified indoor/outdoor unit connecting wire to connect the indoor and outdoor units and fix the wire to the terminal bed securely so that no stress is applied to the connecting section of the terminal bed. Incomplete connection or fixing of the wire could result in a fire.

**[Fig. 7-2-1] (P.8)**

- Ⓐ Screw holding cover (3 pcs.)
- Ⓑ Cover

**[Fig. 7-2-2] (P.8)**

- Ⓐ Terminal bed box
- Ⓑ Knockout hole
- Ⓒ Remove

**[Fig. 7-2-3] (P.8)**

- Ⓐ Use a cable tie to secure the cable.
- Ⓑ Use PG bushing to keep the weight of the cable and external force from being applied to the power supply terminal connector.
- Ⓒ Indoor/outdoor unit connecting wire
- Ⓓ Use ordinary bushing
- Ⓔ Terminal bed for power source and indoor transmission
- Ⓕ Terminal block for remote controller
- Ⓖ Transmission line to the remote controller

## 7. Electrical work

### [Fig. 7-2-4] (P.8)

- Ⓐ Indoor terminal block
  - Ⓑ Earth wire (green/yellow)
  - Ⓒ Indoor/outdoor unit connecting wire 3-core 1.5 mm<sup>2</sup> or more
  - Ⓓ Outdoor terminal block
  - Ⓔ Power supply cord
  - ① Connecting cable  
Cable 3-core 1.5 mm<sup>2</sup>, in conformity with Design 245 IEC 57.
  - ② Indoor terminal block
  - ③ Outdoor terminal block
  - ④ Always install an earth wire (1-core 1.5 mm<sup>2</sup>) longer than other cables
  - ⑤ Remote controller cable  
Wire No × size (mm<sup>2</sup>) : Cable 2C × 0.3  
This wire accessory of remote controller  
(wire length : 10 m, non-polar. Max. 500 m)
  - ⑥ Wired remote controller (option)
  - ⑦ Power supply cord
- Perform wiring as shown in [Fig. 7-2-4] (P.8). (Procure the cable locally.)  
Make sure to use cables of the correct polarity only.
  - Connect the terminal blocks as shown in [Fig. 7-2-4] (P.8).

### ⚠ Caution:

- Use care not to make mis-wiring.
- Firmly tighten the terminal screws to prevent them from loosening.
- After tightening, pull the wires lightly to confirm that they do not move.

## 7.3. Remote controller (wired remote controller (option))

### 7.3.1. For wired remote controller

#### 1) Installing procedures

Refer to the installation manual that comes with each remote controller for details.

#### 2) Initial settings (Remote controller settings)

**Note: Administrator password is required.**

From the Main display, select Main menu>Initial setting, and make the remote controller settings on the screen that appears.  
Refer to the installation manual for the remote controller for how to set the settings.

### Note:

The initial administrator password is "0000." Refer to the installation manual that comes with each remote controller for how to change the password.

## 7.4. Remote controller (wireless remote controller (option))

### 7.4.1. For wireless remote controller (option)

#### 1) Installation area

- Area in which the remote controller is not exposed to direct sunshine.
- Area in which there is no near by heating source.
- Area in which the remote controller is not exposed to cold (or hot) winds.
- Area in which the remote controller can be operated easily.
- Area in which the remote controller is beyond the reach of children.

\* The signal can travel up to approximately 7 meters (in a straight line) within 45 degrees to both right and left of the center line of the receiver.

#### 2) Installing procedures

Refer to the installation manual that comes with each remote controller for details.

### 7.4.2. Signal Receiving Unit

#### 1) Sample system connection

##### [Fig. 7-4-1] (P.9)

- ① Signal receiving unit wiring
- ② Indoor/outdoor wiring

- Ⓐ Outdoor unit
- Ⓑ Refrigerant address
- Ⓒ Indoor unit
- Ⓓ Signal receiving unit

Only the wiring from the signal receiving unit and between the remote controllers is shown in [Fig. 7-4-1]. The wiring differs depending on the unit to be connected or the system to be used.

For details on restrictions, refer to the installation manual or the service handbook that came with the unit.

#### 1. Connecting to Mr. SLIM air conditioner

##### (1) Standard 1:1

- ① Connecting the signal receiving unit  
Connect the signal receiving unit to the CN90 (Connect to the wireless remote controller board) on the indoor unit using the supplied remote controller wire. Connect the signal receiving units to all the indoor units.

#### 2) Installing procedures

Refer to the installation manual that comes with each remote controller for details.

### 7.4.3. Setting

#### 1) Setting the pair number switch

##### [Fig. 7-4-2] (P.9)

##### <Indoor controller board>

#### 1. Setting method

Assign the same pair number to the wireless remote controller as that of the indoor unit. If not doing so, the remote controller cannot be operated. Refer to the installation manual that came with the wireless remote controller for how to set pair numbers of wireless remote controllers.  
Position of daisy wire on the controller circuit board on the indoor unit.

Controller circuit board on the indoor unit (reference)

##### [Fig. 7-4-2] (P.9)

- Ⓐ CN90: Connector for remote controller wire connection

For pair number settings, the following 4 patters (A-D) are available.

Pair number setting pattern	Pair number on remote controller side	Indoor controller circuit board side Point where the daisy wire is disconnected
A	0	Not disconnected
B	1	J41 disconnected
C	2	J42 disconnected
D	3~9	J41 and J42 disconnected

#### 2. Setting example

##### (1) To use the units in the same room

##### [Fig. 7-4-3] (P.9)

- ① Separate setting  
Assign a different pair number to each indoor unit to operate each indoor unit by its own wireless remote controller.

##### [Fig. 7-4-4] (P.9)

- ② Single setting  
Assign the same pair number to all the indoor units to operate all the indoor units by a single wireless remote controller.

##### [Fig. 7-4-5] (P.9)

##### (2) To use the units in different rooms

Assign the same pair number to the wireless remote controller as that of the indoor unit. (Leave the setting as it is at purchase.)

#### 2) Setting the Model No.

- ① Insert batteries.
- ② Press the SET button with something sharp at the end.  
[MODEL SELECT] blinks and Model No. is lighted.
- ③ Press the temp (Ⓜ) (Ⓜ) button to set the Model No.
- ④ Press the SET button with something sharp at the end.  
[MODEL SELECT] and Model No. are lighted for three seconds, then turned off.

Indoor unit model	Model No.
SFZ	026

## 7.5. Service menu

**Note: Maintenance password is required.**

Press Setting on the Main window, and select "Service" to set the maintenance settings.

When the Service menu is selected, a window will appear asking for the password.

##### [Fig. 7-5-1] (P.10)

To enter the current maintenance password (4 numerical digits), move the cursor to the digit you want to change with the [F1] or [F2] button, and set each number (0 through 9) with the [F3] or [F4] button. Then, press the [SELECT] button.

### Note:

- The initial maintenance password is "9999." Change the default password as necessary to prevent unauthorized access. Have the password available for relevant personnel.
- If you forget your maintenance password, you can initialize the password to the default password "9999" by pressing and holding the [F1] button for ten seconds on the maintenance password setting screen.
- Air conditioning units may need to be stopped to make certain settings. There may be some settings that cannot be made when the system is centrally controlled.

## 7.6. Function settings

### 7.6.1. For wired remote controller

Make the settings for the indoor unit functions via the remote controller as necessary.

Select "Function setting" from the Settings menu to bring up the Function setting screen. [Fig. 7-6-1] (P.10)

## 7. Electrical work

### ① [Fig. 7-6-2] (P.10)

- Set the indoor unit refrigerant addresses and unit numbers with the [F1] through [F4] buttons, and then press the [SELECT] button to confirm the current setting.
- When data collection from the indoor units is completed, the current settings will appear highlighted. Non-highlighted items indicate that no function settings have been made. Screen appearance varies depending on the "Unit No." setting.

### ② [Fig. 7-6-3] (P.10)

- Use the [F1] or [F2] button to move the cursor to select the mode number, and change the setting number with the [F3] or [F4] button.

### ③ [Fig. 7-6-4] (P.10)

- When the settings are completed, press the [SELECT] button to send the setting data from the remote controller to the indoor units.
- When the transmission is successfully completed, the screen will return to the Function setting screen.

### 7.6.2. For wireless remote controller

#### [Fig. 7-6-5] (P.10)

- Ⓐ Hour button
- Ⓑ Minute button
- Ⓒ TEMP button
- Ⓓ TEMP button
- Ⓔ ON/OFF button
- Ⓕ CHECK button

### 1. Changing the external static pressure setting.

- Be sure to change the external static pressure setting depending on the duct and the grill used.

#### ① Go to the function select mode

Press the CHECK button (Ⓕ) twice continuously.

(Start this operation from the status of remote controller display turned off.)

CHECK is lighted and "00" blinks.

Press the TEMP button (Ⓒ) once to set "50". Direct the wireless remote controller toward the receiver of the indoor unit and press the Hour button (Ⓐ).

#### ② Setting the unit number

Press the TEMP button (Ⓒ) and (Ⓓ) to set the unit number to 01-04 or AL. Direct the wireless remote controller toward the receiver of the indoor unit and press the Minute button (Ⓑ).

#### ③ Selecting a mode

Enter 08 to change the external static pressure setting using the (Ⓒ) and (Ⓓ) buttons.

Direct the wireless remote controller toward the receiver of the indoor unit and press the Hour button (Ⓐ).

Current setting number: 1 = 1 beep (one second)

2 = 2 beeps (one second each)

3 = 3 beeps (one second each)

#### ④ Selecting the setting number

Use the (Ⓒ) and (Ⓓ) buttons to change the external static pressure setting to be used.

Direct the wireless remote controller toward the sensor of the indoor unit and press the Hour button (Ⓐ).

#### ⑤ To set the external static pressure

Repeat steps (3) and (4) to set the mode number to 10.

#### ⑥ Complete function selection

Direct the wireless remote controller toward the sensor of the indoor unit and press the ON/OFF button (Ⓔ).

#### Note:

- Whenever changes are made to the function settings after installation or maintenance, be sure to record the changes with a mark in the "Check" column of the Function table.

Function table 1

Select unit number 00

Mode	Settings	Mode no.	Setting no.	Initial setting	Check
Power failure automatic recovery (AUTO RESTART FUNCTION)	Not available	01	1	*2	
	Available *1		2	*2	
Indoor temperature detecting	Indoor unit operating average	02	1	○	
	Set by indoor unit's remote controller		2		
	Remote controller's internal sensor		3		
LOSSNAY connectivity	Not Supported	03	1	○	
	Supported (indoor unit is not equipped with outdoor-air intake)		2		
	Supported (indoor unit is equipped with outdoor-air intake)		3		

Function table 2

Select unit numbers 01 to 04 or all units (AL [wired remote controller]/07 [wireless remote controller])

Mode	Settings	Mode no.	Setting no.	Initial setting	Check
Filter sign	100 Hr	07	1		
	2500 Hr		2		
	No filter sign indicator		3	○	
External static pressure	25 Pa	08	1	○	
	40 Pa		2		
	60 Pa		3		
	The same as setting of mode no.08	10	1	○	
0 Pa (set mode no. 08 to 1)	2				

\*1 When the power supply returns, the air conditioner will start 3 minutes later.

\*2 Power failure automatic recovery initial setting depends on the connecting outdoor unit.

**Note:** When the function of an indoor unit were changed by function selection after the end of installation, always indicate the contents by entering a ○ or other mark in the appropriate Check field of the tables.

## 8. How to attach the label and the explanation

The breaker must be turned on at all times except when performing maintenance work or inspection. Hang the supplied label (or the tag) on the breaker (Fig. 8-0-1), and explain to the users that turning off the breaker will cut off the power supply to the refrigerant sensor on the indoor unit, which will result in failure to detect refrigerant leak.

#### Note:

If power to the indoor units and outdoor units are supplied by separate sources, hang the supplied label (or the tag) on the breaker for the indoor units, and explain to the users that the indoor units and outdoor units are connected to different power sources.

## 9. Test run

### 9.1. Before test run

- ▶ After completing installation and the wiring and piping of the indoor and outdoor units, check for refrigerant leakage, looseness in the power supply or control wiring, wrong polarity, and no disconnection of one phase in the supply.
- ▶ Use a 500-volt megohmmeter to check that the resistance between the power supply terminals and ground is at least 1.0 MΩ.
- ▶ Do not carry out this test on the control wiring (low voltage circuit) terminals.

**⚠ Warning:**

Do not use the air conditioner if the insulation resistance is less than 1.0 MΩ.

**Insulation resistance**

After installation or after the power source to the unit has been cut for an extended period, the insulation resistance will drop below 1 MΩ due to refrigerant accumulating in the compressor. This is not a malfunction. Perform the following procedures.

1. Remove the wires from the compressor and measure the insulation resistance of the compressor.
2. If the insulation resistance is below 1 MΩ, the compressor is faulty or the resistance dropped due the accumulation of refrigerant in the compressor.

3. After connecting the wires to the compressor, the compressor will start to warm up after power is supplied. After supplying power for the times indicated below, measure the insulation resistance again.
  - The insulation resistance drops due to accumulation of refrigerant in the compressor. The resistance will rise above 1 MΩ after the compressor is warmed up for two to three hours.  
(The time necessary to warm up the compressor varies according to atmospheric conditions and refrigerant accumulation.)
  - To operate the compressor with refrigerant accumulated in the compressor, the compressor must be warmed up at least 12 hours to prevent breakdown.
4. If the insulation resistance rises above 1 MΩ, the compressor is not faulty.

**⚠ Caution:**

- **The compressor will not operate unless the power supply phase connection is correct.**
- **Turn on the power at least 12 hours before starting operation.**
  - Starting operation immediately after turning on the main power switch can result in severe damage to internal parts. Keep the power switch turned on during the operational season.

### 9.2. Test run

#### 9.2.1. Using wired remote controller

- Make sure to read operation manual before test run. (Especially items to secure safety)

**Step 1 Turn on the power.**

- Remote controller: The system will go into startup mode, and the remote controller power lamp (green) and "PLEASE WAIT" will blink. While the lamp and message are blinking, the remote controller cannot be operated. Wait until "PLEASE WAIT" is not displayed before operating the remote controller. After the power is turned on, "PLEASE WAIT" will be displayed for approximately 3 minutes.
- Indoor controller board: LED 1 will be lit up, LED 2 will be lit up (if the address is 0) or off (if the address is not 0), and LED 3 will blink.
- Outdoor controller board: LED 1 (green) and LED 2 (red) will be lit up. (After the startup mode of the system finishes, LED 2 will be turned off.) If the outdoor controller board uses a digital display, [ - ] and [ - ] will be displayed alternately every second.
- If the operations do not function correctly after the procedures in step 2 and thereafter are performed, the following causes should be considered and eliminated if they are found.

(The symptoms below occur during the test run mode. "Startup" in the table means the LED display written above.)

Symptoms in test run mode		Cause
Remote Controller Display	OUTDOOR BOARD LED Display < > indicates digital display.	
Remote controller displays "PLEASE WAIT", and cannot be operated.	After "startup" is displayed, only green lights up. <00>	• After power is turned on, "PLEASE WAIT" is displayed for 3 minutes during system startup. (Normal)
After power is turned on, "PLEASE WAIT" is displayed for 3 minutes, then error code is displayed.	After "startup" is displayed, green(once) and red(once) blink alternately. <F1>	• Incorrect connection of outdoor terminal block (R, S, T and S <sub>1</sub> , S <sub>2</sub> , S <sub>3</sub> .)
	After "startup" is displayed, green(once) and red(twice) blink alternately. <F3, F5, F9>	• Outdoor unit's protection device connector is open.
No display appears even when remote controller operation switch is turned on. (Operation lamp does not light up.)	After "startup" is displayed, green(twice) and red(once) blink alternately. <EA, Eb>	• Incorrect wiring between the indoor and outdoor unit (Polarity is wrong for S <sub>1</sub> , S <sub>2</sub> , S <sub>3</sub> .) • Remote controller transmission wire short.
	After "startup" is displayed, only green lights up. <00>	• There is no outdoor unit of address 0. (Address is other than 0.) • Remote controller transmission wire open.
Display appears but soon disappears even when remote controller is operated.	After "startup" is displayed, only green lights up. <00>	• After canceling function selection, operation is not possible for about 30 seconds. (Normal)

**Step 2 Switch the remote controller to "Test run".**

- ① Select "Test run" from the Service menu, and press the [SELECT] button. [Fig. 9-2-1] (P.11)
- ② Select "Test run" from the Test run menu, and press the [SELECT] button. [Fig. 9-2-2] (P.11)
- ③ The test run operation starts, and the Test run operation screen is displayed.

**Step 3 Perform the test run and check the airflow temperature.**

- ① Press the [F1] button to change the operation mode.  
Cooling mode: Check that cool air blows from the unit.  
Heating mode: Check that warm air blows from the unit.

**Step 4 Confirm the operation of the outdoor unit fan.**

The speed of the outdoor unit fan is controlled in order to control the performance of the unit. Depending on the ambient air, the fan will rotate at a slow speed and will keep rotating at that speed unless the performance is insufficient. Therefore, the outdoor wind may cause the fan to stop rotating or to rotate in the opposite direction, but this is not a problem.

**Step 5 Stop the test run.**

- ① Press the [ON/OFF] button to stop the test run. (The Test run menu will appear.)
- Note:** If an error is displayed on the remote controller, see the table below.

## 9. Test run

- For description of each check code, refer to the following table.

① Check code	Symptom	Remark	
P1	Intake sensor error		
P2, P9	Pipe (Liquid or 2-phase pipe) sensor error		
E6, E7	Indoor/outdoor unit communication error		
PA	Forced compressor error		
P6	Freezing/Overheating safeguard operation		
EE	Communication error between indoor and outdoor units		
P8	Pipe temperature error		
E4	Remote controller signal receiving error		
FB (Fb)	Indoor unit control system error (memory error, etc.)		
FL	Refrigerant leak		
FH	Refrigerant sensor error		
PL	Refrigerant circuit abnormal		
PB (Pb)	Indoor unit fan motor error		
E0, E3	Remote controller transmission error		
E1, E2	Remote controller control board error		
E9	Indoor/outdoor unit communication error (Transmitting error) (Outdoor unit)		For details, check the LED display of the outdoor controller board.
UP	Compressor overcurrent interruption		
U3, U4	Open/short of outdoor unit thermistors		
UF	Compressor overcurrent interruption (When compressor locked)		
U2	Abnormal high discharging temperature/49C worked/insufficient refrigerant		
U1, Ud	Abnormal high pressure (63H worked)/Overheating safeguard operation		
U5	Abnormal temperature of heat sink		
U8	Outdoor unit fan safeguard stop		
U6	Compressor overcurrent interruption/Abnormal of power module		
U7	Abnormality of super heat due to low discharge temperature		
U9, UH	Abnormality such as overvoltage or voltage shortage and abnormal synchronous signal to main circuit/ Current sensor error		
Others	Other errors (Refer to the technical manual for the outdoor unit.)		

- On wired remote controller

① Check code displayed in the LCD.

### 9.2.2. Using wireless remote controller (option)

[Fig. 9-2-3] (P.11)

- Ⓐ TEST RUN button
- Ⓑ MODE button
- Ⓒ FAN button
- Ⓓ VANE button

- ① Turn on the power to the unit at least 12 hours before the test run.
- ② Press the TEST RUN button Ⓐ twice continuously.  
(Start this operation from the status of remote controller display turned off.)  
TEST RUN and current operation mode are displayed.
- ③ Press the MODE button Ⓑ to activate COOL mode, then check whether cool air is blown out from the unit.
- ④ Press the MODE button Ⓑ to activate HEAT mode, then check whether warm air is blown out from the unit.
- ⑤ Press the FAN button Ⓒ and check whether fan speed changes.
- ⑥ Press the ON/OFF button to stop the test run.

#### Note:

- Point the remote controller towards the indoor unit receiver while following steps ② to ⑥.
- It is not possible to run the in FAN, DRY or AUTO mode.

## 9. Test run

[Output pattern A] Errors detected by indoor unit

Wireless remote controller Beeper sounds/OPERATION INDICATOR lamp flashes (Number of times)	Wired remote controller Check code	Symptom	Remark
1	P1	Intake sensor error	
2	P2, P9	Pipe (Liquid or 2-phase pipe) sensor error	
3	E6, E7	Indoor/outdoor unit communication error	
6	P6	Freezing/Overheating safeguard operation	
7	EE	Communication error between indoor and outdoor units	
8	P8	Pipe temperature error	
9	E4	Remote controller signal receiving error	
10	–	–	
11	PB (Pb)	Indoor unit fan motor error	
12	FB (Fb), FL, FH	Indoor unit control system error (memory error, etc.)/Refrigerant leak/Refrigerant sensor error	
14	PL	Refrigerant circuit abnormal	
No sound	– –	No corresponding	

[Output pattern B] Errors detected by unit other than indoor unit (outdoor unit, etc.)

Wireless remote controller Beeper sounds/OPERATION INDICATOR lamp flashes (Number of times)	Symptom	Remark
1	Indoor/outdoor unit communication error (Transmitting error) (Outdoor unit)	For details, check the LED display of the outdoor controller board.
2	Compressor overcurrent interruption	
3	Open/short of outdoor unit thermistors	
4	Compressor overcurrent interruption (When compressor locked)	
5	Abnormal high discharging temperature/49C worked/insufficient refrigerant	
6	Abnormal high pressure (63H worked)/Overheating safeguard operation	
7	Abnormal temperature of heat sink	
8	Outdoor unit fan protection stop	
9	Compressor overcurrent interruption/Abnormal of power module	
10	Abnormality of super heat due to low discharge temperature	
11	Abnormality such as overvoltage or voltage shortage and abnormal synchronous signal to main circuit/Current sensor error	
12	–	
13	–	
14	Other errors (Refer to the technical manual for the outdoor unit.)	

\*1 If the beeper does not sound again after the initial two beeps to confirm the self-check start signal was received and the OPERATION INDICATOR lamp does not come on, there are no error records.

\*2 If the beeper sounds three times continuously “beep, beep, beep (0.4 + 0.4 + 0.4 sec.)” after the initial two beeps to confirm the self-check start signal was received, the specified refrigerant address is incorrect.

- On wireless remote controller

The continuous buzzer sounds from receiving section of indoor unit.

Blink of operation lamp

- On wired remote controller

Check code displayed on the LCD.

- If the unit cannot be operated properly after the above test run has been performed, refer to the following table to remove the cause.

Symptom		Cause
Wired remote controller	LED 1, 2 (PCB in outdoor unit)	
PLEASE WAIT	For about 3 minutes following power-on	After LED 1, 2 are lighted, LED 2 is turned off, then only LED 1 is lighted. (Correct operation)
PLEASE WAIT → Error code	After about 3 minutes has expired following power-on	Only LED 1 is lighted. → LED 1, 2 blink.
Display messages do not appear even when operation switch is turned ON (operation lamp does not light up).		Only LED 1 is lighted. → LED 1, 2 blinks twice, LED 2 blinks once.

On the wireless remote controller with conditions above, following phenomena takes place.

- No signals from the remote controller are accepted.
- OPE lamp is blinking.
- The buzzer makes a short ping sound.

### Note:

Operation is not possible for about 30 seconds after cancellation of function selection. (Correct operation)

For description of each LED (LED1, 2, 3) provided on the indoor controller, refer to the following table.

LED 1 (power for microcomputer)	Indicates whether control power is supplied. Make sure that this LED is always lit.
LED 2 (power for remote controller)	Indicates whether power is supplied to the remote controller. This LED lights only in the case of the indoor unit which is connected to the outdoor unit refrigerant address “0”.
LED 3 (communication between indoor and outdoor units)	Indicates state of communication between the indoor and outdoor units. Make sure that this LED is always blinking.

## 9. Test run

### 9.3. AUTO RESTART FUNCTION

#### Indoor controller board

This model is equipped with the AUTO RESTART FUNCTION.

When the indoor unit is controlled with the remote controller, the operation mode, set temperature, and the fan speed are memorized by the indoor controller board.

The auto restart function sets to work the moment the power has restored after power failure, then, the unit will restart automatically.

Set the AUTO RESTART FUNCTION using the remote controller. (Mode no.01)

## 10. Maintenance

### 10.1. Gas charge

[Fig. 10-1] (P.11)

- Ⓐ Indoor unit
- Ⓑ Union
- Ⓒ Liquid pipe
- Ⓓ Gas pipe
- Ⓔ Stop valve
- Ⓕ Outdoor unit
- Ⓖ Refrigerant gas cylinder operating valve
- Ⓗ Refrigerant gas cylinder for R32 with siphon
- Ⓘ Refrigerant (liquid)
- Ⓢ Electronic scale for refrigerant charging
- Ⓚ Charge hose (for R32)
- Ⓛ Gauge manifold valve (for R32)
- Ⓜ Service port

1. Connect gas cylinder to the service port of stop valve (3-way).
2. Execute air purge of the pipe (or hose) coming from refrigerant gas cylinder.
3. Replenish specified amount of refrigerant, while running the air conditioner for cooling.

#### Note:

In case of adding refrigerant, comply with the quantity specified for the refrigerating cycle.

#### ⚠ Caution:

- Do not discharge the refrigerant into the atmosphere. Take care not to discharge refrigerant into the atmosphere during installation, reinstallation, or repairs to the refrigerant circuit.
- For additional charging, charge the refrigerant from liquid phase of the gas cylinder. If the refrigerant is charged from the gas phase, composition change may occur in the refrigerant inside the cylinder and the outdoor unit. In this case, ability of the refrigerating cycle decreases or normal operation can be impossible. However, charging the liquid refrigerant all at once may cause the compressor to be locked. Thus, charge the refrigerant slowly.

To maintain the high pressure of the gas cylinder, warm the gas cylinder with warm water (under 40°C) during cold season. But never use naked fire or steam.







## AIR CONDITIONER INDOOR UNIT

MODEL \_\_\_\_\_ SERVICE REF. \_\_\_\_\_

OPERATE	<COOLING>						<HEATING>					
RATED VOLTAGE	220		230		240		220		230		240	
FREQUENCY	50	60	50	60	50	60	50	60	50	60	50	60
RATED INPUT<INDOOR ONLY> kW												
RATED CURRENT<INDOOR ONLY> A												

PHASE \_\_\_\_\_

WEIGHT \_\_\_\_\_

REFRIGERANT \_\_\_\_\_

SERIAL No. \_\_\_\_\_

ALLOWABLE PRESSURE \_\_\_\_\_

IP CODE \_\_\_\_\_

YEAR OF MANUFACTURE \_\_\_\_\_


### MITSUBISHI ELECTRIC CORPORATION

MITSUBISHI ELECTRIC CONSUMER PRODUCTS (THAILAND) CO., LTD.  
700/406 MOO 7, TAMBON DON HUA ROH, AMPHUR MUANG, CHONBURI 20000, THAILAND  
MADE IN THAILAND

---

This product is designed and intended for use in the residential,  
commercial and light-industrial environment.

Please be sure to put the contact address/telephone number on  
this manual before handing it to the customer.



**MITSUBISHI ELECTRIC CORPORATION**

HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN